

# Installation Instructions

## Cane Touch Apron Replacement Kits

This kit is designed to be used with:  
**HAC, HVR, HVRGRN, EMABF, VRC & VRCGRN models**  
 manufactured after July 2007.

### Installation Procedure:

- Using cane apron as a template use a center punch to mark hole locations on front of left and right side panels.
- Drill 1/8" diameter holes at marked locations. (Center punch hole locations before drilling). When drilling the right hand hole on refrigeration units, be certain to drill straight.  
**CAUTION:** Keep the drill bit away from the refrigeration condenser. If the drill damages or punctures the condenser refrigeration tubing severe and expensive damage to the refrigeration system will result.
- Loosen and remove (2) front screws from underside of cooler dispenser panels.
- Install cane touch apron to underside of cooler dispenser panels and reuse fasteners removed in step 3 above.
- Attach lower edges of apron to cooler side panels with screws provided. (Using two holes drilled in step 2 above)

### Required Tools:

To install this kit the following tools are required:

- Phillips Head Screwdriver
- Pinned Torx Head Driver
- Power Drill with 1/8" Drill Bit
- Hammer and Center Punch

CANE TOUCH APRON REPLACEMENT KITS (COLOR OPTIONS)	
*KIT PART NO.	FINISH
98324C	Stainless Steel (For all Models)
98312C	Platinum Vinyl (HAC/HVR)
98313C	Light Gray Vinyl (EMABF/VRC)

\*Kits consist of cane apron, screws and pinned torx bits.

